


sureshotgps
GENIUS G1
know the distance

User Manual
Version 1.0



*This manual is version 1.0 and the most up to date version at the time of publishing.
For any updates please visit our website www.sureshotgps.com*

Quick Start Guide to the Sureshotgps™ Genius G1

Thank you for purchasing the Sureshotgps™ Genius G1.

For your convenience the Sureshotgps™ Genius G1 is preloaded with maps and ready for immediate use. It is highly recommended that you register the device for warranty purposes and software updates.

What's included:

- Sureshotgps™ Genius G1
- Quick start guide
- Mini USB cable




Table of Contents

	Page
Getting to know your Sureshotgps™ Genius G1	5
1.0 Prior to use	6
Charging	6
Registering	6
2.0 Ready to Play	6
3.0 Main Menu	6
Automatic Course Recognition	7
4.0 Hole Selection	8
Automatic hole advance (AHA)	8
Selecting your start hole	8
Play Golf (Green View)	8
5.0 Page information	9
Scorecard	9
Editing Par and Score	9
Shot Distance	9
Edit Course	10
6.0 Settings Menu	11
Metre/Yard Option	11
ResetRound Time	11
Backlight Value	11
Auto Shutoff	12
Auto Hole Advance	12
Set Time Zone	12
Set Time Format	13
Odometer	13
Device Info	13


Table of Contents

	<i>Page</i>
7.1 Sureanalysis Software	14
System Requirements	14
8.0 FAQ's	14
9.0 Limited Warranty	15
10.0 Declaration of Conformity	17
11.0 Software Licensing	17

sureshotgps
GENIUS G1
know the distance



Getting to know your Sureshotgps™ Genius G1



Satellite signal

Battery status

Menu/Power Key: to power on/off and access main menu

Page switching key: to switch between displayed page, set starting point of shot distance and correct course data

Navigation 5-way key

1.0 Prior to use

Charging

It is important that the battery has been charged before use. Using the USB cord provided, plug the USB connection into the charging port on the back of the unit [under rubber cover]. Now plug the other end into the USB port on your computer. Full charging will take at least 4 hours.

Registering

It is recommended that you register your Sureshotgps™ Genius G1 for warranty purposes. Follow the easy instructions at www.sureshotgps.com/register. Updates to software will only be possible if you have registered.

2.0 Ready to Play

Your Sureshotgps™ Genius G1 comes preloaded with Australian and New Zealand golf courses. To make it easy to find courses, the unit will automatically display the five closest golf courses to your location. You can then select the course you want to play.

NOTE: this feature only works once you arrive at the golf course and has GPS reception.

3.0 Main Menu

Hold the Menu button down for three (3) seconds until the unit is turned on.

The GPS will begin searching for satellites as shown in the picture. To skip this and go straight to the main menu press the Menu button.

In the main menu you will see three (3) options:

<Play Golf>
<Settings>
<Power off>

Use the 5-way key to move from one option to another. To enter, push down on the middle of the 5-way key.




3.0 Main Menu

Automatic Course Recognition

For best GPS reception always ensure you are in an open area.

When you are at the course select **Play Golf**.

The Sureshotgps™ Genius G1 Auto Course Recognition will highlight the closest five (5) courses to you. You can choose from the courses displayed, or < Select Course > to choose your own course from the course list.



If there are no courses located, the device will show an error message. Please press the middle of the 5-way key to get into the courses list where you will be able manually select a course you are interested in. After you select a course, you will automatically move to the Play Golf page



4.0 Hole Selection

Automatic hole advance (AHA)

This feature allows you to move around the golf course without having to change the hole you are viewing. It can be turned on or off.

The AHA requires the unit to go within 15m of the centre of the green and then move away 19m from the centre of the green - the Sureshotgps™ Genius G1 will then advance to the next hole.

You can manually select a hole by turning off this feature off in the Auto Hole Advance option in settings.

Manually selecting your start hole

Please choose the hole that you would like to start at. You can do this by pressing Right/Left on the 5-way key. Press the Middle key to see information about the hole.

Play Golf (green view)

This display will show you the relative distances between you and the Front, Centre and Back side of the putting green. Press Up/Down on the 5-way key to switch holes.



5.0 Page Information

In Play Golf, press right of the 5 way key to access Scorecard at any time throughout the round.

Scorecard

Scorecards provide relevant information to the fairway. It will display hole number, par and scores. The Sureshotgps™ Genius G1 automatically calculates total value and the differences between par and your score. Press Left on the 5 way key to go back to Play Golf.

Editing Par and Score

Press the Middle of the 5-way key to edit Par and Score. Use Up/Down key to switch between the two and the Right/Left key to edit the score. Once you have entered your par and score press the middle key again to return to Scorecard. To return to Play Golf press Left of the 5 way key.

Shot distance

In Play Golf press right twice on the 5 way key to access the Shot Distance page.

The Shot Distance function can let you measure your shot distance easily and precisely. When starting your shot, press the Page key to set your current position, the value will be reset to 0. While walking to your ball the screen will display the distance from the start point to your current position instantly.

Press Up/ Middle key to hold the distance calculation for <End>.

To start a new measurement, press Up/ Middle key to release from <HOLD> and press Page to reset for a new start point. You can use the pointer of swing distance function to make an easy measurement on the distance between any two points on the course.



5.0 Page Information

Edit Course

In Play Golf press left on the 5 way key to access the Edit Course page.

The GPS green location information is determined on the actual course situation when the information is collected. In the event the green location has had some changes, you can use this function to edit it.

In the Edit Course page, please press the PAGE key and select <Edit>, you should see a black mark on the screen.

Press the Up/Down key to switch focus to the location you would like to calibrate, then press PAGE key to confirm the change.

For example, if you are going to correct the distance of the green centre on the first hole, please press the Up/Down key to choose the first hole on the Green View page after you get to the green centre; then press Up/Down key to switch the focus to the green center column, and press PAGE to reset as <0>, which means the distance between you and the green center is 0.

You can also use Up/Down key to choose the Front or Back side of the green to mark corrections continuously after finishing the correction on green centre distance.

The above method is available when you want to correct the Front, Centre and Back side of putting green of any course. However you need to move to the Front, Centre and Back side of green prior to corresponding corrections.

To return to Play Golf press Right of the 5 way key.



6.0 Settings Menu

From the Main Menu, select Settings by pressing the Middle button on your 5-ways key.

Metre/Yard Option

The distance unit is preset to Metre. If you want to change it, you can choose <Yard/Metre> on the settings menu and use the Right/ Left key to change the unit setting. Press Menu to return to the Main Menu.

Reset Round Time

The device provides you a simple timer to help you record the time spent in the Play Golf section after locating a satellites. You can reset the timer to zero at any time by selecting < Reset Round Time > and pressing the Page key, the timer will then return to zero.

If you want to know present play time during a play, please go to the Green View page. Press Menu to return to the Main Menu.

Backlight

This device provides an <Auto Backlight Off> function to save power. If any key is not touched for a specific time period the screen will turn to dark automatically.

Using the Right/Left key you can increase or decrease the backlight duration. There are several selections to choose from: 1min, 3min, 10min, 30min and on (backlight always on). Press Menu to return to the Main Menu.



6.0 Settings Menu

From the Main Menu, select Settings by pressing the Middle button on your 5-ways key.

Auto Shutoff

This device provides an <Auto Shutoff> function to save power. If you set the power timeout, the device will turn off automatically after the timer if you don't touch any key for the set time period.

To set press the Right/Left key to change the settings. You will have several selections to choose from: On, 30min, 40min, 50min, 60min,70min, 80min, 90min, 100min, 110min and 120min. Press Menu to return to the Main Menu.

Automatic Hole Advance

Once you have finished putting and are walking to the next hole, the device will automatically advance on to the next sequent hole as you move around the course.

You can turn on/off this function by pressing the Right/ Left key in <Auto Hole Advance> under settings. You can then manually select the hole as you are golfing. Press Menu to return to the Main Menu.

Set time zone

The device will set the present time zone automatically according to relevant data of GPS satellites. You can adjust the time zone of your location if needed by entering <Time Set Zone> and using the Right/Left key to increase or decrease the times.

Press Menu to return to the Main Menu.



6.0 Settings Menu

From the Main Menu, select Settings by pressing the Middle button on your 5-ways key.

Set time format

Directly under <Time Set Zone> you will see the <Set Time Format>.

Change the time format from 12 or 24 hours by using the Right/Left buttons on the 5-way key. Press Menu to return to the Main Menu.

Odometer

The device provides an odometer option so you can track the distance you cover. You can turn this function on or off by pressing Right/Left on your 5 way key.

Device information

You can check model, software/ hardware version and product serial number (S/N) of the Sureshotgps™ Genius G1 by selecting <Device Info> and then pressing Page. You can go back to the Setting Menu by pressing Page again.



7.0 Sureanalysis Software

Sureanalysis (Sureshotgps™ Genius G1) allows you to update the course library on your Sureshotgps™ Genius G1. Even though the Sureshotgps™ Genius G1 comes with courses pre-loaded, we are continually updating our course library by adding new courses and updating existing ones.

Sureanalysis allows you to keep your Sureshotgps™ Genius G1 updated with the latest course data.

Please note: Before download the latest version of a course you must first delete the old version from the Sureshotgps™ Genius G1.

System requirements

Compatible with Windows XP, Vista (32 & 64 bit), Windows 7 and Windows 8. Sureshotgps™ Genius G1 is not compatible with Apple (Mac OS)

8.0 Frequently Asked Questions (FAQ)

Who can help me with technical questions & support?

Our friendly team is available on Live chat or email at support@sureshotgps.com. It is recommended you contact us first rather than returning to the place of purchase for the fastest response to your enquiry.

How do I download or update my courses?

SureAnalysis works only in conjunction with our website.

Go to www.sureshotgps.com and click on "My SureshotGPS". From the menu, you can interact with your Sureshotgps™ Genius G1. To interact with the Sureshotgps™ Genius G1, it needs to be connected via the USB port.

How do I reset my Sureshotgps™ Genius G1?

Simultaneously hold the "page" button and the "toggle key" to the right. Hold both for 5 seconds and release.

9.0 Limited Warranty

Sureshotgps™ Pty Ltd (“SS”) warrants the Sureshotgps™ Genius G1 device delivered in this package will be free from material defects for one (1) year following the date of purchase from SS or its authorised reseller. The accessories included in the package including USB cable, are covered for material defects for one (1) year. For the purpose of this warranty, “material defect” means any defect in a SS product that can be reproduced by SS and is a substantial nonconformity from the published specifications for such product. SS shall not be responsible for any loss or damage whatsoever resulting from any defect in or associated with its products which occur or are notified by the purchaser to SS or its authorised repairer more than one year from said date of purchase.

This Limited Warranty does not apply to normal wear and tear or if any component of the Sureshotgps hardware is opened or repaired by an unauthorised person or company, and does cover repair or replacement of any Sureshotgps hardware damaged by: MISUSE, MOISTURE OR LIQUIDS, EXPOSURE TO HEAT, ACCIDENT, ABUSE OR NEGLIGENCE.

Dropping your Sureshotgps™ Genius G1 can permanently damage the receiver, which is not covered under the terms of the Limited Warranty.

This Limited Warranty does not cover physical damage to the surface of the Sureshotgps, including cracks or scratches on the LCD screen.

Neither the manufacturer or distributor or reseller shall be responsible for data that may be damaged or lost at any time. As the SS may gain information either through USB or wireless technology, we cannot guarantee the successful transmission of information.

This Limited Warranty does not extend to any defects which have been caused or contributed by neglect, misuse or accident, nor in respect of product which has been altered by other than authorised SS personnel or its authorised repairers.

The determination as to whether the terms of this warranty are to apply to returned products is within the sole discretion of SS or its authorised repairer. Provided any returned product is determined to be covered by this warranty, SS or its authorised repairers shall at SS’s sole discretion, repair or replace, free of charge, any products or parts thereof.

9.0 Limited Warranty

In no event whatsoever shall SS be liable for any incidental, special or consequential loss or damage resulting from the purchase and/or use of its products howsoever caused and howsoever claimed. Any liability on SS under this warranty in respect of any repair and /or replacement and/or any action involving any of its products shall be limited to and not exceed the purchase price of the product in question. The terms of this warranty are subject to relevant provisions of any Federal, State or Municipal law. Any dispute or action in relation to this warranty or the construction of it shall be subject to and conducted in accordance with the laws of Victoria, Australia.

Before returning any product, contact the SS Customer Support Group and obtain an RA number. Visit the Sureshotgps™ web site www.sureshotgps.com for support contact details. If the Customer Support Group verifies that the product is likely to be defective they will issue an RA number to place on the outer package in which the product will be shipped. SS cannot accept any product without an RA number on the package. Warranty returns must also be accompanied by a copy of the dated proof of purchase. Deliver the product along with the RA number to SS. If you ship the product you must assume the risk of damage or loss in transit.

You must use the original container (or the equivalent) and pay the shipping charge. SS may replace or repair the product with either a new or reconditioned product and the returned product becomes SS's property.

SS warrants the repaired or replaced product to be free from material defects for a period of the greater of (i) ninety (90) days from the return shipping date; or (ii) the period of time remaining on the original one (1) year warranty.

If there is any inconsistency between this Limited Warranty and any Warranty included in the packaging of the Sureshotgps, the provisions of this Limited Warranty shall apply.

10.0 Declaration of Conformity

We, Sureshotgps™ Pty. Ltd declare under our sole responsibility that the Sureshotgps™ conforms to all world standards of compliance.



Sureshotgps™ Pty. Ltd. operates a policy of continuous development. Sureshotgps™ Pty. Ltd. reserves the right to make changes and improvements to the Sureshotgps™ and any other of its products without prior notice.

The contents of this document are provided “as is”. Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchant - ability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Sureshotgps™ Pty. Ltd reserves the right to revise or withdraw it at anytime without prior notice.

11.0 Software licensing

This product contains embedded software. You have a non-exclusive, non-transferable right to use the software only as embedded in the hardware and may not copy, disassemble or attempt to reverse engineer the software or use it on any other hardware.

The software includes software supplied to SS by third parties (“Suppliers”) which is provided without warranty by such Suppliers. The software is owned by SS or its Suppliers and is protected by copyright laws and laws protecting trade secrets, intellectual property and confidential information.